Where you risk jamming the saw by a falling log end, use one of these methods:

Method 1

Both saw cuts (or only the undercut) are made at a slight angle. Start with the top cu down to about 1/3 of the diameter and then continue with the bottom cut. This allo the log to fall – and the saw is set free.

Method 2

The saw cuts are slightly separated. Start with the top cut down to about 1/3 of the diameter and then continue with the bottom cut. This allows the log to fall – and th saw is set free.

LAST EDITED

October 13, 2025

COMMENTS ON THIS TOPIC?

Contact us

BOOKMARK & SHARE